

# Label Off



Gel sticker remover.





## **Properties:**

- High efficiency
- Gel consistency
- Sensitive to all surfaces

### **Advantages:**

- Pleasant odour
- Simple use
- Quick application

#### **Applications:**

**RETECH Label Off** is a highly efficient professional product for quick and sensitive removal of glue residue left after foils, stickers, masking tape, labels, cellotape, textile tape, etc. **RETECH Label Off** can be used in many applications on all common surfaces such as varnish, glass, metal, ceramic, wood, plastic, polycarbonate, leather, faux leather, and more.

#### Order codes:

Name	Storage code	Package	Volume / Size	Order number
Label Off	LOFF	Bottle	1L	1 37700
Label Off 5 L	L0FF5	Canister	5L	1 37701



#### Instructions for use:

- 1. Remove the PVC sticker, label, plastic foil etc. the usual way before using the product.
- 2. Apply evenly on the surface and leave for 1-2 minutes.
- 3. Remove the dissolved glue remnants with RETECH Microfibre Cloth.
- 4. Leave for longer in order to remove old hardened glue, or repeat the procedure.
- **Note:** The product isn't suitable for materials with surface treatment sensitive to chemical solvents, as it may dry out or discolour them. These are typically metallic plastic parts. Before using on this type of material it is recommended to test the product on a small, concealed area.

#### **ONLY FOR PROFESSIONAL AND INDUSTRIAL USE!**

#### **Technical data:**

Colour:	Transparent		
pH:	6-7		
Density:	0,90 – 0,95 g/ml		
Application temperature:	5°C - 30°C		

#### Storage:

In a dry place at a temperature +5 °C to +30 °C. Protect from direct sunlight and subzero temperatures.

#### **Healt and Safety:**

Health and Safety information is available in the Material Safety Data Sheet and on the label.

#### **Declaration:**

The information and recommendations in this publication are to the best of our knowledge reliable. However nothing herein is to be construed as a warranty or representation. Users should make their own tests to determine the applicability of such information or the suitability of any products for their own particular purposes. Statements concerning the use of the products described herein are not to be construed as recommending the infringement of any patent and no liability for infringement arising out of any such use is to be assumed.

#### Address:

RETECH, s.r.o., Vackova 1541/4; Praha 5 - Stodůlky; Czech Republic Contact address: 285 02 Suchdol u Kutné Hory cp. 212; tel./fax: +420 327 596 128; e-mail: info@retech.cz